


OLD DASH WIRELESS STEERING WHEEL DIAGRAM




CONNECTIONS IN ENGINE BAY



WARNING: DO NOT CONNECT
MODULE AT STEERING WHEEL BEFORE
WIRING HORN LOOM IN ENGINE BAY

CONNECTIONS IN STEERING WHEEL



PRE-AIRBAG MODEL
STEERING WHEEL DIAGRAM